

TELEMATICS



We have the hardware factory installed for you, after you tell us what features you want, we'll take it from therel

In these 3 simple steps:

- 1. Log in to Hinoultimate.com
- 2. Select your TSP* and desired trucks
- 3. Your Service provider will follow up and you can enjoy seamless integration.

HINO TRUCKS TSP PARTNERS:











*This requires a HINO Trucks TSP partner. HINO is working to add new partners who could join at any time. To get the most up-to-date TSP list, please visit: Hino.com

HINO TRUCKS APP





SCAN TO PUT THE POWER OF **EDGE AT YOUR** FINGERTIPS!



Available on Desktop at: Or Download the App at: www.hinoultimate.com

hino.com/mobile
















GET LOGGED IN

Getting started is easier than ever!

Simply Log-On at hinoultimate.com with the username and password provided in your welcome email.

Once logged in, you have access all of your fleet's real time data.

Then it's all about setting the system up the way that works best for you. Just go to the settings section of the portal and you can create new users, change times zones and select your preferred language and unit of measure.



Management tab, you can see all open cases.



All 2022 and newer HINO L-SERIES and HINO XL-SERIES equipped.

The HINO Dashboard allows you to view your fleet location, nearest dealer and how your fleet's utilization compares to others.



With HINO Benchmarking, you'll see a graphical snapshot of how you're doing compared to other similar vehicles in similar situations. Idle times, fuel economy... whatever data you need to optimize the performance of your fleet, you can find it here in real time. Never fly blind again! Everything you need to maximize your fleet's ROI is right here, right now.